# E65/E80 GBW PASSCODES

### SERVICE: 6781

### DEEP: 9512867

#### Factory reset:

Tapping the dial =enter Tap the dial on the right to enter menu Scroll to "Safety & Password enter Press dial "log-in" and scroll to "123" enter Enter passcode 9512867 and return arrow to enter.

Tap top left button twice and scroll to Service Menu and enter Scroll down to "Reset" and enter. Once you've re-set, turn off the grinder and back on. You are now factory reset

## Setting scale Resolution/Frequency

Follow steps to get to password Enter service password 6781 Tap upper left button twice Scroll to "Settings" enter Scroll to "internal pre-sets" enter Scroll to "GBW Resolution" enter Set to "Low"

Back out of Program menu by pushing upper left dial twice and you're good to go.